

**Amalgam Pluggers / Condensers / Applicators**




**1830**  
BEHRMAN (Fig. 1)



**1831**  
BLACK (Fig. 1-2)



**1832**  
MORQUETTE (Fig. 0/1)



**1833**  
Black Action 11/12 Plugger



**1834**  
Hollenback No. 1 Plugger



**1835**  
Hollenback No. 2 Plugger



**1836**  
Hollenback No. 3 Plugger



**1837**  
Blacks 0-1 (1mm-1.5mm)



**1838**  
Blacks 1-2 (1.5mm-2.5mm)




**1843**  
.7mm-1mm



**1839**  
Bodkin 1 (.7mm-1mm)



**1844**  
1mm-1.5mm



**1840**  
Bodkin 2 (1.5mm-2mm)



**1845**  
1.5mm-2mm




**1841**  
2.5mm-3mm



**1846**  
Oregon (Fig. 3)



**1842**  
Oregon 2



**1847**  
Oregon (Fig. 4)



**1848**  
UP 12



**1849**  
Applicator 1-2



**1850**  
Birtles Applicator Spatula



**1851**  
Birtles Applicator Spatula K

# Placement Instruments, Stopping Stoppers, Pluggers

## Placement Instruments



## Stopping Stoppers



## Pluggers



## Burnishers



1864  
Fig. 1



1865  
Fig. 28/29



1866  
Fig. 34



1867  
Fig. 27/29



1868  
Fig. 21B



1869  
ACORN  
Fig. 21

# Burnishers

